


S Sandberg®
ACTIVE 

Outdoor Solar Powerbank 16000




Quick guide

420-35




www.sandberg.world

Charge Powerbank




| Battery mAh | Battery Watt-hours | Solar panel Watt | Charging time by sun | Charging time by USB 1A | Charging time by USB 2.4A | Charging time by USB C 18W |
|-------------|--------------------|------------------|----------------------|-------------------------|---------------------------|----------------------------|
| 16000 | 59.2 Wh | 1.4W | 51 hours | 13 hours | 5 hours | 4 hours |

Charge devices



Charge one smartphone and one tablet or two smartphones by USB-A.



Or charge one smartphone or one tablet by USB-C.

Flashlight procedure



Press once to 100% brightness



Press again to 25% brightness



Press once again to strobe



Press once to turn off LED light



Hold about 3 seconds for SOS



Support

<http://helpdesk.sandberg.world>

Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty

5
Years
Warranty

For information on handling electronic waste, see www.sandberg.world/weee



100%