

## Instructions for extra warm white and warm white Christmas lights- 123ink.ie brand

### 9 light functions

With the remote control included and the button on the adapter, you can easily switch between the nine different light settings. The remote control has a range of up to 2 metres and works with a CR 2025 battery (included). The button on the adapter itself also allows you to switch between the light functions. The functions are as follows:

- 1. Combination:** Combination between warm white and extra warm white, contains both slow fades and twinkle effects.
- 2. Steady on:** Warm white lighting with no effects.
- 3. Steady on:** Extra warm white lighting without effects.
- 4. Slo-glo:** Warm white lighting that flickers slowly and quickly.
- 5. Slo-glo:** Extra warm white lighting that flickers slowly and quickly.
- 6. Sequential:** Alternating extra warm white and warm white lighting, flickering.
- 7. Twinkle:** Alternating extra warm white and warm white lighting, flickering quickly.
- 8. Slow fade:** Alternating extra warm white and warm white lighting, with a slow transition.
- 9. Slo-glo:** Alternating extra warm white lighting and warm white lighting, with a slow fade.

### Dimming the Christmas lights

For every light function, the lighting can also be dimmed with the remote control. There are four positions: 100%, 75%, 50% and 25%. By pressing the buttons, you can turn the lighting 25% brighter or dimmer.

### Setting the timer

Insert the plug into the socket and select the desired light function. Once you have chosen this, you can set the timer. You can do this via the adapter or via the remote control. The timer ensures that the lighting switches off automatically after 8 hours. Then the lights will come on again after 16 hours. This means that the light comes on again at exactly the same time the next day. As long as the timer is active, this process continues to repeat itself.

#### Switch on via remote control:

To activate the timer function via the remote control, press the timer button. The green light on the adapter then indicates that the timer is on. To turn off the timer, press the timer button on the remote control again. The green light on the adapter will then go out.

#### Enable via adapter:

To enable the timer function via the adapter, press the black button on the adapter for 3 seconds. The green light then indicates that the timer is on. To turn off the timer at the switch, press the button again for 3 seconds. The green light will then go out again.

#### **Example:**

*If you have switched on the timer at 4:00 PM, the lighting will switch on automatically 8 hours later (at 12:00 AM) The lighting remains off for 16 hours. The lights are turned on again at 4:00 PM the next day.*

**Of course, these 123ink products come with a 100% lifetime guarantee.**